



ACCESS PLATFORM ASSEMBLY MANUAL

Model Numbers:
FS13597 / FS13599



**READ THESE INSTRUCTIONS COMPLETELY
BEFORE STARTING WORK**

WARNING:

Failure to comply with all instructions
may result in serious injury.

Before assembling this product,
identify all components.

If any components are missing or damaged,
return to the place of purchase.

Do not substitute any components.

ATTENTION:

For Goods Returns,
this package must be in original condition.

If the contents are opened and or
partially assembled they will not be
accepted as a returnable item.



ASSEMBLY CONFIGURATIONS



Standard Configuration




Shelf Configuration




Walk Thru' Configuration




COMPONENT LIST




Front Section




Rear Section




Platform



LHS
Wheel System



RHS
Wheel System




Component Kit


- Fastener Kit A
- Fastener Kit B
- Fastener Kit C
- Plan Brace (x2)
- Plastic Wedge Spacer
- Bent Tube Spanner
- Allen Key



Top Diagonal Brace (x2)




Horizontal Brace (x2)




Bottom Diagonal Brace (x2)




COMPONENT LIST




Rear Upright




Top Handrail




Top Handrail




Shelf Kit




Rear Panel



Bottom Handrail
(x2)




Lower Handrail
(Access Platform 10 x 2)
(Access Platform 12 & 14 x 4)



Safety Gate (x2)





Handlever
(x2)




Handle




Step 1: Assemble Platform and Front Section



Fastener Kit A





Sizing Template for
M8x20mm Screws (x2)




Do Not Tighten Any Fasteners Until After Step 7.


Step 2: Assemble Platform and Rear Section







Front of
Rear
Section








Sizing Template for
M8x20mm Screws (x2)






Step 3: Assemble Top Diagonal Braces to Platform and Front Section






Step 4: Assemble LHS and RHS Wheel Systems to Front Section and Rear Section





Step 5: Assemble Plan Braces to Wheel Systems and Rear Section



Step 6: Assemble Horizontal Braces to Front and Rear Section






Fastener Kit C





M8x45mm Screws (x4)



Step 7: Assemble Bottom Diagonal Braces to Front Section and Rear Section




Fastener Kit C





Firmly Tighten All Fasteners
Assembled In Steps 1 Through 7.

Use The Bent Tube Spanner
And Allen Key Supplied In The
Component Kit.


Do Not Over-Tighten Fasteners.




Step 8: Assemble Handlebars to Wheel Systems



Fastener Kit B






M8x20mm Screws (x4)







Do Not Tighten Any Fasteners Until After Step 17.





Step 9: Assemble Handle to Handlevers




Step 10: Assemble Rear Upright to Platform



Step 11: Assemble Rear Panel to Rear Upright





**Skip This Step When Assembling
The Walk Thru' Configuration.**




M8x80mm Screws (x2)








Step 12: Assemble Top Handrail to Rear Upright





**Safety Gate Pivot Position Can Be
Assembled On The LHS or RHS.**





Step 13: Assemble Bottom Handrails to Top Handrails and Front Section





Step 14: Assemble Lower Handrails to Front Section




Fastener Kit C




Step 15: Assemble Front Safety Gate to Top Handrails





Fastener Kit B




M8x60mm Screws (x1)





Step 16: Assemble Rear Safety Gate to Rear Upright




**Insert Only One (1) Screw
When Assembling
The Walk Thru' Configuration.**



Step 17: Assemble Shelf to Top Handrails




**Skip This Step When Not Assembling
The Shelf Configuration.**





Firmly Tighten All Fasteners
Assembled In Steps 8 Through 17.















Use The Bent Tube Spanner
And Allen Key Supplied In The
Component Kit.

Do Not Over-Tighten Fasteners.



Spare Parts Diagram



A	 Shelf FS23212	H	 Castors (x4) FS23239
B	 Rear Panel FS23216	I	 Feet (Front & Rear) FS23240
C	 Top Diagonal Braces (x2) FS23217	J	 Handle & Handrails Access Plat. 3 FS23230 Access Plat. 4 FS23231 Access Plat. 5 FS23232 Access Plat. 6 FS23233 Access Plat. 7 FS23234 Access Plat. 8 FS23235 Access Plat. 10 FS23236 Access Plat. 12 FS23237 Access Plat. 14 FS23238
D	 Horizontal Braces (x2) (Access Platform 10-14) FS23218	K	 Lower Handrails (x2) (Access Platform 10-14) FS23215
E	 Bottom Diagonal Braces (x2) (Access Platform 10-14) FS23219	L	 Bottom Handrails (x2) FS23214
F	 Plan Braces (x2) FS23220	M	 RH Top Handrail LH Top Handrail Safety Gates (x2) FS23213
G	 Wheel System (RHS & LHS) Access Plat. 3 FS23221 Access Plat. 4 FS23222 Access Plat. 5 FS23223 Access Plat. 6 FS23224 Access Plat. 7 FS23225 Access Plat. 8 FS23226 Access Plat. 10 FS23227 Access Plat. 12 FS23228 Access Plat. 14 FS23229	N	 Component Kit FS23241

